

## Feeders and accessories for SMT-pick and place machines M1 – P50

Stand: 07.2025

Order no.	Designation	Description
<b>Trays</b>		
<b>P1.1</b>	Magnetic tray holders - 1 set	6 magnetic bracket - for 2 trays
<b>P1.1.1</b>	Magnetic tray holder - 1 pc	for trays
<b>P1.2</b>	Magnetic PCB bracket	
<b>P1.3</b>	Magnetic PCB support pin	
<b>Manual feeders</b>		
<b>P2.1</b>	Manual strips feeder block	10 tapes x 8mm wide Length=100mm
<b>P2.1.3.1</b>	Manual strips feeder block - magnetic	1 tape x 8mm wide Length=300mm
<b>P2.1.3.6</b>	Manual strips feeder block - magnetic	6 tapes x 8mm wide Length=300mm
<b>P2.2</b>	Manual strips feeder block	5 tapes x 12mm wide Length=100mm
<b>P2.2.3.1</b>	Manual strips feeder block - magnetic	1 tape x 12mm wide Length=300mm
<b>P2.2.3.5</b>	Manual strips feeder block - magnetic	5 tape x 12mm wide Length=300mm
<b>P2.3</b>	Manual strips feeder block	5 tapes x 16mm wide Length=100mm
<b>P2.3.3.1</b>	Manual strips feeder block - magnetic	1 tape x 16mm wide Length=300mm
<b>P2.4.3.1</b>	Manual strips feeder block - magnetic	1 tape x 24 mm wide Length=300mm
<b>P2.5.3.1</b>	Manual strips feeder block - magnetic	1 tape x 32 mm wide Length=300mm
<b>P2.6.3.1</b>	Manual strips feeder block - magnetic	1 tape x 44 mm wide Length=300mm
<b>P2.7</b>	Manual strips feeder block	4X8 + 2x12 + 2x16mm Length=100mm
<b>P2.8</b>	manual stick feeder	up to 8mm wide Length=100mm
<b>P2.8.1</b>	manual stick feeder	up to 8+12+16mm wide Length=100mm
<b>P2.8.2</b>	manual stick feeder	3x up to 8 wide Length=100mm
<b>P2.9</b>	manual stick feeder	up to 12mm wide Length=100mm
<b>P2.9.1</b>	manual stick feeder	3 x up to 12mm wide Length=100mm
<b>P2.10</b>	manual stick feeder	up to 16mm wide Length=100mm
<b>P2.10.1</b>	manual stick feeder	3 x up to 16mm wide Length=100mm
<b>Automatic smart feeders</b>		
<b>P3.1</b>	automatic tape feeder	8mm wide
<b>P3.2</b>	automatic tape feeder	12mm wide
<b>P3.3</b>	automatic tape feeder	16mm wide
<b>P3.4</b>	automatic tape feeder	24mm wide
<b>P3.5</b>	automatic tape feeder	32mm wide
<b>P3.6</b>	automatic tape feeder	44mm wide
<b>P3.7</b>	automatic stick feeder	up to 8mm wide
<b>P3.8</b>	automatic stick feeder	up to 12mm wide
<b>P3.9</b>	automatic stick feeder	up to 16mm wide
<b>P3.10</b>	automatic stick feeder	up to 24mm wide
	other sizes available on request	
<b>P3.XXN</b>	Adapters for components	for example P3.SOT16
<b>Magazine for reels</b>		
<b>P4.1</b>	Magazine for ca. 40 reels	reels Ø=175mm

<b>P4.2</b>	Magazine for ca. 20 reels	reels Ø=175mm
<b>P4.3</b>	Magazine for ca. 40 reels	reels Ø=175mm and Ø=330mm
<b>P4.5</b>	Separating plate for reels	reels Ø=175mm
<b>P4.6</b>	Separating plate for reels	reels Ø=330mm
<b>Stands ( Tables )</b>		
<b>P6.1</b>	for P1 / P10 / P20 / P30	
<b>P6.2</b>	for P40 / P 50	
<b>Stands with monitor- and keyboard brackets</b>		
<b>P7.1</b>	for the P1 / P10 / P20 / P30	
<b>P7.2</b>	for the P40 / P 50	
<b>Conveyors</b>		
<b>P8.1</b>	for P1 / P10 / P20 / P30 incl. SMEMA L=1050mm	Variable width from 200 mm to 340mm
<b>P8.2</b>	for P1 / P10 / P20 / P30 incl. SMEMA L=1450mm	Variable width from 200 mm to 340mm
<b>P8.3</b>	for P40 / P50 incl. SMEMA L=1050mm	Variable width from 200 mm to 340mm
<b>P8.4</b>	for P40 / P50 incl. SMEMA L=1450mm	Variable width from 200 mm to 340mm
<b>Complete heads</b>		
<b>P9.1</b>	Pick & place head for P1, P10, P20; P30	incl. software + hardware
<b>P9.2</b>	Dispensing head for P10, P30 – piston valve	incl. software + hardware
<b>P9.3</b>	Dispensing head for P10, P30 – auger valve	incl. software + hardware
<b>P9.6</b>	Pick & place head for P40; P50 – single head	incl. software + hardware
<b>P9.7</b>	Dispensing head for P50 – piston valve	incl. software + hardware
<b>P9.8</b>	Dispensing head for P50 – auger valve	incl. software + hardware
<b>Nozzle changer</b>		
<b>P10.1</b>	Nozzle changer	for P1, P10, P20, P30